

WIND PROTECTION *Ride like the wind in comfort with the right height & style windshield and accessories.*

Lock & Ride® Windscreen

Install or remove without tool. Required, sold separately: Mounting Brackets (2876374).

2877837-01 Low: 25" (64 cm)
2877838-01 Mid: 28" (71 cm)
2877839-01 Tall: 30" (76 cm)
2856677 Lock & Key



Mini Standard Windscreen

Requires Windscreen Clamp Set (2874679), sold separately. 16" tall.

2875581 Windscreen
2874679 Clamps



Black Superfly Windscreen

Fits model year '05-17.

2874936 12"



Superfly Windscreen With Cowl Mount

9.5" wide x 12" high. Holds the Hammer passenger seat cowl. Fits model year '05-11.

2876290



STORAGE *Versatile storage for weekend rides or daily commutes.*

Leather Tool Roll

4" (10cm) D x 11.5" (29cm) L.

2872579



Leather Saddlebags

Requires Brackets (2875008), sold separately. Fits model year '05-17.

2876161 Saddlebags
2875008 Brackets



HANDLEBARS *Change your riding dynamic with the bar height & reach that fit you.*



Arlen Ness® Fly Handlebars

Requires Brakeline Kit (1911359) '08-17 or (1911358) '05-07 Fits model year '05-17.

2878125-156 ▲ Chrome
2878125-266 ▲ Black



Vee Drag Bars

Fits model year '05-17.

2878126-156 Chrome
2878126-266 Black

▲ Handlebar Height Warning: legal handlebar heights are regulated by state and local laws. Accessory handlebars may not be legal in all areas or for all riders. Check your state and local regulations for more information.

HAMMER® S CRUISER

INTRO
2-17

MIDSIZE
18-29

CRUISER
30-65

BAGGER
66-107

TOURING
108-135

ELECTRIC
136-137

MADE FOR
VICTORY®
138-141

GARAGE
142-143

INDEX
144